

SLIDE VALVES



APPLICATION

These valves are used for on and off at the entrance of pneumatic circuit.

ADVANTAGES

It releases out compressed trapped air from pneumatic closed circuit at shut off position and avoid accidents.

INSTALLATION INSTRUCTIONS

All slide valves should always be installed, air inlet from male threading and pneumatic close circuit to female threading.

WORKING PRESSURE

Valves are designed to withstand working pressure up to 150 PSI.

AVAILABILITY OF SIZES

Available in 1/4" BSP, 1/2" BSP.